



Code Name	ScanLogic	Functions
Chang code	00000	- Allows changing of any code - 0,0,0,0,0 cannot be changed
Manager code	12345	- Allows manager to open safe - Opens programming (multiple functions) *Must be Change
Reset code	00000	- Resets all codes to factory default - Does not open safe

Programming

ScanLogic Basic

A. Open lock

- 1) Enter default Manager code 123456

B. Change Code

- 1) Enter 000000
- 2) Enter existing code, 1 beep
- 3) Enter new 6 digit code, 1 beep
- 4) Repeat new 6 digit code, 2 beeps

**Manager code of 123456 must be changed before any other Users can be added; Manager code cannot be changed back to 123456*

***Reset Code must be changed from default*

****1 long beep means code is not allowed*

C. Add Manager fingerprint(s)

- 1) Open with Manager code
- 2) Hold "+," and hold until 2 beeps
- 3) Place fingerprint 4X, 1 beep each
- 4) 2 beeps confirms fingerprint addition

**Manager can add up to 5 fingerprints*

D. Add User1 Code

- 1) Open with Manager code
- 2) Hold "1," 1 beep
- 3) Enter new 6 digit code, 1 beep
- 4) Repeat new 6 digit code, 2 beeps

E. Add User2 Code

- 1) Open with User1 code
- 2) Hold "1," 1 beep
- 3) Enter new 6 digit code, 1 beep
- 4) Repeat new 6 digit code, 2 beeps

F. Add fingerprints

- 5) Open with User 1code
- 6) Hold "+," 1 beep
- 7) Place fingerprint 4X, 1 beep each
- 8) 2 beeps confirms fingerprint addition

**User1 can add up to 5 fingerprints*

G. Delete own fingerprints (All)

- 1) Open with User 1 code
- 2) Hold "-", 2 beeps

**All of your fingerprints have been deleted*

**Not for manager fingerprint.*

H. Delete User2 (Code & fingerprints)

- 1) Open with User1 code
- 2) Hold "3", 2 beeps

**User2 code are deleted*

I. Delete All (Codes/fingerprints)

- 1) Open with manager code
- 2) Hold "3", 2 beeps

**Manager code remains unchanged, User1 and User2 are deleted*

J. Reset (resets codes to factory default)

- 1) Input reset code, in back erwelop
- 2) Hold "6", 2 beeps

**Lock is in default mode, Manager code reverts to 123456, Reset code remains unchanged*

K. Turn beeper off

- 1) Open with Manager or User1 code
- 2) Hold "4," 1 beep

L. Turn beeper on

- 1) Open with Manager or User1 code
- 2) Hold "4," 2 beeps

Security Levels:

Security Level 1 = Fingerprint or code

Security Level 2 = Fingerprint **and** code

M. Change to Security Level 2 (fingerprint and code)

- 1) Open with Manager or User1 code/fingerprint
- 2) Hold "5," 1 beep, then 2 beeps

N. Change to Security Level 1 (fingerprint or code)

- 1) Open with Manager or User1 code **and** fingerprint
- 2) Hold "5," 1 beep, then 1 beep